

OPERATION OF VIDEO TRIPODS

Tripods and their plates must stay together and require attention to detail during checkout and check in; a tripod without its mounting plate is useless.



CHECKOUT INCLUDES:

The tripod includes its mounting plate (what screws into the camera) and/or a carrying bag. The swivel head also has an extension arm for panning a camera when a camera is mounted.

OPERATION: The mounting plate has a universal screw that fits all video cameras. The legs lock but should not be overly cranked when tightened. The center column rises up for more height and should be in the down position when it goes out and when it is put back on the shelf. It should be stored with all legs and the extension arm tight around its length.